









## Test Cases 2.1



Test Case 2.1A	
<b>Objective:</b> Verify that the NAO robot can scan the text of a physical book using its camera, recognize the text using OCR, and translate it into speech. (Successful)	
<b>Test Type:</b> Functional	<b>Execution Type:</b> Manual
<b>Setup:</b> <a href="#"></a> <ul style="list-style-type: none"><li>• Ensure that the NAO robot is powered on and connected.</li><li>• Ensure that the camera is functional.</li><li>• The laptop's camera is functional and the environment is well-lit.</li><li>• The physical book or document to be scanned is placed in a well-lit environment.</li></ul>	
<b>Pre-Conditions:</b> <a href="#"></a> <ul style="list-style-type: none"><li>• The camera is working</li><li>• The text in the physical book is clear and legible.</li><li>• The camera is positioned correctly to capture the text.</li></ul>	
<b>Robot</b> (Successful)	<b>Laptop</b> (Successful)
<b>Test Steps:</b> <a href="#"></a> <ol style="list-style-type: none"><li>1. Start the NAO robot and ensure the camera is active and pointing at the text in the physical book.</li><li>2. Place text in front of the camera.</li><li>3. Nao robot reads out the text.</li><li>4. Confirm that the recognized text matches the text in the physical book.</li></ol>	<b>Test Steps:</b> <a href="#"></a> <ol style="list-style-type: none"><li>1. Type "hi, readmate" and place the text in front of the laptop camera to initialize the robot and begin text recognition.</li><li>2. Type "readmate, start read" to initiate reading</li><li>3. The recognized text is outputted to the console and the NAO robot reads the text aloud.</li><li>4. Listen to the NAO robot to ensure it reads the recognized text accurately.</li></ol>
	 <p>initialize start reading</p>
<b>Expected Result:</b> <a href="#"></a> <ul style="list-style-type: none"><li>• The NAO robot successfully captures the image, recognizes the text, and can translate the text into speech.</li></ul>	
<b>Time Constraint:</b> Minimum: 2 minutes  Maximum: 5 minutes	

<b>Test Case 2.1A - Invalid</b>	
<b>Objective:</b> Verify that the NAO robot correctly handles invalid or challenging scenarios when attempting to scan text from a physical book, ensuring it does not produce incorrect or unintended speech output. (Success)	
<b>Test Type:</b> Negative/Functional	<b>Execution Type:</b> Manual
<b>Setup:</b>  <ul style="list-style-type: none"> <li>• Ensure that the NAO robot is powered on and connected.</li> <li>• Ensure that the camera is functional.</li> <li>• The laptop's camera is functional and the environment is well-lit.</li> <li>• The physical book or document to be scanned is placed in a well-lit environment.</li> </ul>	
<b>Pre-Conditions:</b>  <ul style="list-style-type: none"> <li>• The camera is working</li> <li>• The text in the physical book is clear and legible.</li> <li>• The camera is positioned correctly to capture the text.</li> </ul>	
<b>Laptop</b>	<b>Robot</b>
	<b>Test Steps:</b>  <ol style="list-style-type: none"> <li>1. Type <b>"hi, readmate"</b> and place the text in front of the laptop camera to initialize the robot and begin text recognition.</li> <li>2. <b>Use a blank page or a page with no text:</b> Verify that the robot does not attempt to read and provides the feedback <b>"I could not recognize any text."</b></li> <li>3. <b>Use a page with handwritten notes:</b> Verify that the robot either fails to recognize the text accurately and say <b>"I could not recognize any text."</b></li> <li>4. <b>Use a page with overlapping or heavily marked text (e.g., text underlined with thick markers):</b> Verify that the robot fails to recognize the text and say <b>"I could not recognize any text."</b> or produces garbled/unintelligible speech output.</li> <li>5. <b>Use a page with curved or wrinkled pages:</b> Verify that the robot cannot accurately recognize the text due to distortion and say <b>"No text recognised"</b>.</li> <li>6. <b>Dim the lighting around the robot or create shadows over the text and initiate the scanning process:</b> Verify that the robot fails to recognize the text properly and say <b>"No text recognised"</b>.</li> <li>7. <b>Use a page with text in a language that the robot's OCR does not support (e.g., Arabic, Japanese, etc.):</b> Verify that the robot either does</li> </ol>

	not recognize the text and say <b>"No text recognised"</b> .
	
<b>Expected Result:</b> <a href="#">🔗</a> <ul style="list-style-type: none"> <li>The NAO robot should only say <b>"No text recognised"</b>.</li> </ul>	
<b>Time Constraint:</b> <a href="#">🔗</a> <ul style="list-style-type: none"> <li><b>Minimum:</b> 5 min</li> <li><b>Maximum:</b> 10 min</li> </ul>	
<b>Test view:</b> <a href="#">🔗</a>	

Test Case 2.1B	
<b>Objective:</b> Verify that the NAO robot can remember where it stopped reading text so that it can resume from the same position the next time it starts reading. (Successful)	
<b>Test Type:</b> Functional	<b>Execution Type:</b> Manual
<b>Setup:</b> <a href="#">🔗</a> <ul style="list-style-type: none"> <li>Ensure that the NAO robot is powered on and connected.</li> <li>The robot has access to text content, either through a scanned image using its camera or a preloaded text.</li> </ul>	
<b>Pre-Conditions:</b> <a href="#">🔗</a> <ul style="list-style-type: none"> <li>The NAO robot is connected and responsive.</li> <li>The robot has started reading some text.</li> <li>The system has a mechanism to store and retrieve the last reading position.</li> </ul>	
<b>Laptop</b> (KIV)	<b>Robot</b> (Success)
	<b>Test Steps:</b> <a href="#">🔗</a> <ol style="list-style-type: none"> <li>Type <b>"hi, readmate"</b> and place the text in front of the laptop camera to initialize the robot and begin text recognition.</li> <li>Type <b>"readmate, start read"</b> to initiate reading.</li> <li>Type <b>"readmate, pause reading"</b>, ensure that the laptop replies with "pausing..." and stops reading the text.</li> <li>Type <b>"readmate, continue reading"</b>, ensure that the laptop replies with "Continuing..." and the laptop continues to read the text from where it left off.</li> </ol>

	
<b>Expected Result:</b>	
The robot should begin reading from the position where it last stopped.	
<b>Time Constraint:</b>	
Minimum: 2 minutes	
Maximum: 5 minutes	
<b>Test Case 2.1B - Invalid</b>	
<b>Objective:</b>	
Verify that the NAO robot can handle invalid inputs when trying to stop reading text and resume from the same position the next time it starts reading. (Successful)	
<b>Test Type:</b> Negative/Functional	<b>Execution Type:</b> Manual
<b>Setup:</b> 	
<ul style="list-style-type: none"><li>• Ensure that the NAO robot is powered on and connected.</li><li>• The robot has access to text content, either through a scanned image using its camera or a preloaded text.</li></ul>	
<b>Pre-Conditions:</b> 	
<ul style="list-style-type: none"><li>• The NAO robot is connected and responsive.</li><li>• The robot has started reading some text.</li><li>• The system has a mechanism to store and retrieve the last reading position.</li></ul>	
<b>Laptop</b> (KIV)	<b>Robot</b> (Success)
	<b>Test Steps:</b> 
	<ol style="list-style-type: none"><li>1. Type "hi, readmate" and place the text in front of the laptop camera to initialize the robot and begin text recognition.</li><li>2. <b>Use invalid commands to pause the reading:</b> type "readmate, pause"/ "stop" / "enough" or any other unrecognizable commands to try to pause the reading. Ensure that reading does not continues and the robot returns "Unknown command, please try again"</li><li>3. Type "readmate, stop reading", ensure that the laptop replies with "pausing..." and stops reading the text.</li><li>4. <b>Use invalid commands to continue the reading:</b> type "readmate, go on" / "continue" / "proceed with the reading" or any other unrecognizable commands to try to continue the</li></ol>

	<p>reading. Ensure that reading does not continues and the robot returns <b>“Unknown command, please try again”</b></p> <p>5. Type <b>“readmate, continue reading”</b>, ensure that the laptop replies with <b>“Continuing...”</b> and the laptop continues to read the text from where it left off.</p>
	 <p>Invalid commands to pause and continue reading</p>
<p><b>Expected Result:</b> </p> <p>The robot should not accept any other commands except <b>“readmate, stop reading”</b> and <b>“readmate, continue reading”</b> and will reply with <b>“Unknown command, please try again”</b> for every other non-valid commands.</p>	
<p><b>Time Constraint:</b></p> <p>Minimum: 2 minutes</p> <p>Maximum: 5 minutes</p>	

**Test Case 2.1C (Same as 1.2B)**